# **Configure default route to the routers:**

#### **Procedure:**

- 1. Three routers are placed on the same level and connected using serial DCE cable. The three routers are named as router0, router1 and router2.
- 2. A switch called switch0 is placed alongside router0 and another called switch1 is placed alongside router2. The connection between routers and switches is done using copper staright-through cables.
- 3. Two generic computers are placed alongside each switch. For switch0 the computers are named PC0 and PC1. For switch1 computers are named PC2 and PC3.
- 4. IP addresses and default gateway addresses are configured seperately for all four computers.
- 5. The terminal of each router is accessed and the interfaces for each connection is established with specified gateway addresses.

### **Observations:**

- 1. Pinging any destination computer from any source initially gives an error stating *destination host unreachable* because there is no direct connection between source and destination.
- 2. The ip route of the routers can be seen using *show ip route* command for each router.
- 3. In order to send ping message irrespective of destination addresses via routers we add default routes to routers router0 and router2. This can be done as follows:
  - For router0:
     Route through 10.0.0.0 and 20.0.0.0 is directly connected. Therefore, we add default route with next hop address as 20.0.0.2.

    Router(config)#ip route 0.0.0.0 0.0.0.0 20.0.0.2
  - For router2:
    Route through 30.0.0.0 and 40.0.0.0 is directly connected. Therefore, we

add default route with next hop address as 30.0.0.1. Router(config)#ip route 0.0.0.0 0.0.0.0 30.0.0.1

#### 4. For router1:

Route through 20.0.0.0 and 30.0.0.0 is directly connected. Therefore, we add static route through 10.0.0.0 and 40.0.0.0.

Router(config)#ip route 10.0.0.0 255.0.0.0 20.0.0.1 Router(config)#ip route 40.0.0.0 255.0.0.0 30.0.0.2

5. After adding default routes to routers, router0 and router2, a connection is established between each interface and pinging from any source to any destination works as per the requirement.

## **Learning Outcomes:**

- 1. Configuring a topology with multiple routers.
- 2. Configuring IP and default gateway addresses for PCs.
- 3. Configuring IP addresses for interfaces.
- 4. Configuring static IP routes for ping messages to give the desired response since they give an error if there is no direct connection between device networks.
- 5. Configuring default IP routes to routers such that irrespective of destination address the packet is forwarded to the next hop address specified.